


Manual Reverse Purge (MRP) System

Can be used in Hazardous and Ordinary Locations/Areas



The Manual Reverse Purge (MRP) System allows for the cleaning of caked-on powder off of the filter thus maximizing performance. The filter cleaning is achieved by having the air intake reversed through the filter thus purging the clogged filter.

The Manual Reverse Purge (MRP) works by :

- 1 - Closing the slider on the opening to block the suction intake orifice for approximately 5 seconds while the vacuum is running and then
- 2 - Quickly opening the Purge Valve. Air is now flowing backwards through the filter via the valve removing any caked on dust particles

Keep Purge Valve open for 1-2 seconds then close (repeat above steps 2 or 3 times). Reverse Purge System will cause dust to fall off of the filter.
